
Slueair400 Series Blueair400 Series











THANK YOU FOR CHOOSING BLUEAIR

Ready to start breathing cleaner air? First, read this User Guide to ensure that you use the Blueair300/Blueair400 safely and effectively. Then plug it in, turn it on and... breathe. Don't hear anything? Check the blue "power on" light. Blueair is so quiet, you may not realize it's on. But as the patented Blueair system removes dust, pollen, smoke, gases and odors from your indoor environment, we think you'll notice the difference.

GENERAL SAFETY INSTRUCTIONS

The Blueair300/Blueair400 is an electrical appliance. Before using it for the first time, please read these safety instructions and take precautions to reduce the risk of fire, electric shock and injury. (And keep in mind the Limited Warranty applies only if the unit is used according to instructions.)

To reduce the risk of electric shock, the Blueair300/Blueair400 will automatically turn off when the front door is opened for cleaning and filter replacement. Additionally, the unit has a grounding type plug (with a third pin) that will only fit a grounding type outlet. If the plug does not fit your outlet, contact a licensed electrician to install a grounded outlet. Do not alter the plug in any way.

To avoid electric shock and fire hazards, plug the Blueair300/Blueair400 directly into an appropriate electrical outlet (see voltage label on your unit) using the cable provided. The cable is packaged beneath the unit.





Do not allow foreign objects to enter the ventilation or exhaust openings. This may cause electric shock or damage to the unit.

Never try to repair or adjust any of the electrical or mechanical functions on your Blueair300/Blueair400 yourself. Contact your local dealer or Blueair for service center information.

Use only authorized Blueair filters.

USING YOUR BLUEAIR

Place the unit in a location that allows air to circulate freely in, out and around the unit.

Do not place the unit:

- Directly on or against soft furnishings (such as bedding or curtains).
- Near electronically sensitive devices (such as a computer within 67/10cm).
- Near sources of heat (such as radiators, fireplaces or ovens).
- Near oxygen tanks or other combustible gases.

Do not let the Blueair come in contact with water. It is not designed for use outdoors or in wet areas (such as bathrooms).

SETTINGS

When turning on the Blueair after the unit has been off, turn the speed control to level 3 for a few minutes of fast initial cleaning. Then adjust the control to the desired speed:

- 1. HEPASilent™ (for nighttime use).
- 2. Moderate fan speed (for daytime use).
- 3. Maximum operation (for fast initial cleaning or very polluted air).

For best results, run your Blueair300/Blueair400 24 hours a day, 7 days a week. Continuous operation means you get a continuous supply of clean, filtered air circulating throughout the room.

How It Works

Built-in carry handles

3-speed control knob (on side)

Blue "power on" light

Airflow output

Easy-to-change filter – no tools required

Galvanized Swedish steel housing


Ion brushes (no ozone generated)

Easy-to-vacuum ion chamber

Airflow intake

Power source and cord

Safety switch automatically turns power off when door opens







KEEP YOUR BLUEAIR LOOKING GOOD AND WORKING WELL

The Blueair300/Blueair400 features award-winning Swedish design, materials and workmanship. Keep your unit in top condition with these cleaning tips:

- Wipe the exterior with a soft, clean, damp cloth.
- Vacuum the small inlets with a soft brush attachment.
- Vacuum inside the ion chamber by opening the front door of the unit and opening the door of-- the ion chamber (right-hand side).
- Never clean with gasoline, chemical solvents or corrosive materials they may damage the surface.

HELP KEEP THE PLANET HEALTHY

At Blueair, we're in the business of clean air. Our air purifiers are designed for maximum improvement of indoor air, with minimum impact on the natural world.

The particle filter is made of polypropylene, which breaks down into water and carbon dioxide when burned.

All major parts are made from high-quality galvanized steel.

The external parts have been powder coated for endurance and environmental protection (with no introduction of chemical outgassing).

The Blueair300/Blueair400 is energy efficient. From lowest to highest speed, it uses no more than a light bulb.

Blueair air purifiers are built for years of use. They are also designed to be disassembled and the components sorted and recycled.

FILTERS

Patented HEPASilent™ technology makes the Blueair 300/Blueair400 incredibly quiet. Units come with one HEPASilent™ particle filter (installed):

Particle Filter – includes 1 particle filter that removes dust, pollen, bacteria, pet dander, mold spores and other airborne particles. The particle filter is made of polypropylene, which mechanically filters out airborne particles. To maximize filter effectiveness, particles are negatively charged before reaching the filters.

SmokestopTM Filter – contains active carbon and is recommended for use in rooms where heavy gaseous pollutants such as cigarette and cigar smoke or other VOCs (volatile organic compounds, such as household paints) are present. On first use you may notice a slight odor from the active carbon; this will dissipate quickly.

For optimal performance Blueair recommends that you replace filters every six months.

We offer a convenient Filter Subscription Program (not available in all countries). For information or to place an order, contact your local dealer or Blueair.


IMPORTANT! Use only Blueair filters to ensure proper functioning and to qualify your unit for full warranty coverage.

Changing the Filters

1 Open the front door; power to the unit will automatically switch off.




Remove old filter.



3 Vacuum filter space.



Replace with new filter; use Blueair filters only.



6 Close front door.



LIMITED WARRANTY

Blueair warrants that your Blueair Air Purifier will be free from defects in material or workmanship for a period of ten (10) years from the date of purchase provided that you have completed and returned your warranty registration within 30 days of purchase of your air purifier to Blueair, and that the filters are replaced with original Blueair replacement filters at least every six (6) months (the "Limited Warranty"). Otherwise the standard warranty time in your country applies.

Within the first 30 days of purchase Blueair will replace the defective unit at no charge to you and reimburse any shipping charges. After 30 days, Blueair's obligation and liability under this Limited Warranty is limited to repairing or replacing (at its sole discretion) the defective unit and paying the freight cost of returning the unit to you. The Limited Warranty does not cover replacement filters.

In the event of a malfunction or failure of your Blueair Air Purifier, please contact your local dealer to obtain a return authorization number and the address of the nearest Blueair Repair Center. If you are unable to contact your local dealer, please contact Blueair directly at the addresses listed in your User Guide. The return authorization number must be clearly written on the outside of the shipping box or the shipment may be refused.

Your Limited Warranty remains in effect only if your Blueair Air Purifier:

- 1. Is operated in accordance with the instructions provided.
- 2. Has had its filter changed with original Blueair replacement filters at least once every six (6) months.
- 3. Is connected to a proper power supply (see voltage label on machine).
- **4.** There is no evidence of tampering, mishandling, neglect, accidental damage, modification, and/or repair done to the Blueair Air Purifier by anyone other than authorized Blueair service personnel.
- 5. Your warranty registration has been completed and returned to Blueair.

This Limited Warranty is provided by Blueair Inc. in North America and Blueair AB outside of North America and contains the only express warranty provided to you.

BLUEAIR DISCLAIMS ANY EXPRESS WARRANTY NOT PROVIDED HEREIN AND ANY IMPLIED WARRANTY, GUARANTEE OR REPRESENTATIONS AS TO THE SUITABILITY FOR ANY PARTICULAR PURPOSE, PERFORMANCE, QUALITY AND ABSENCE OF HIDDEN DEFECTS, AND ANY REMEDY FOR BREACH OF CONTRACT, WHICH BUT FOR THIS PROVISION, MIGHT ARISE BY IMPLICATION, OPERATION OF LAW, CUSTOM OF TRADE OR COURSE OF DEALING, INCLUDING IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. EXCEPT AS PROVIDED IN THIS AGREEMENT, BLUEAIR FURTHER DISCLAIMS ANY RESPONSIBILITY FOR LOSSES, EXPENSES, INCONVENIENCES, SPECIAL, INDIRECT, SECONDARY OR CONSEQUENTIAL DAMAGES ARISING FROM OWNERSHIP OR USE OF THE PRODUCTS.

This Limited Warranty gives you specific legal rights and you may also have other rights which may vary upon legal jurisdiction.



BUSINESS REPLY MAIL

FIRST-CLASS MAIL PERMIT NO 21034-001 CHICAGO IL

POSTAGE WILL BE PAID BY ADDRESSEE



BLUEAIR INC 17 N State St., Ste. 1830 CHICAGO IL 60602

hilledleedleedlikeddeleddeleddeledd

PLEASE FOLD AND SEAL WITH TAPE OR GLUE. DO NOT STAPLE

Blueair 300/400 Series

Warranty Card

NO POST AGE NECESSARY IF MAILED IN THE UNITED STATES

Blueair 300/400 10 Year Limited Warranty. Name Address City Phone E-mail Date Purchased: Dealer Purchased From: Serial number: Where did you buy this product?

Retail Store Reason for Buying: Allergies (Check all that apply) Asthma

Please complete and return this form within 30 days of purchase in order to receive your State Zip Internet Catalog General Indoor Air Quality Concern Smoker in the Home O Pets in the Home Children with Allergies/Asthma Other Medical Condition (Please describe) Other (Please describe) Were you offered the Filter Subscription Program that automatically If no, would you like information ships replacement filters every six months? Yes No on this program? Yes No If this product were available in a different color, which color would you prefer? Are there other features that you would have liked to see on this product?



Filter Subscription

Use this Order Form for Free Delivery and Automatic Shipment of Filters. 300/400 Series

I would like to red	ceive free delivery of the Particle Filter	; twice a year.	
I would like to red	ceive free delivery of the Smokestop.	Filter twice a year.	
First filter to be s	hiped		
lame			
Company			
address			
ii+v.	State	7in	
ity	State	Zip	
hone	Fax		
-mail			
Credit Card			
	signing my name below, I hereby authorize Blueair to bill m		
	wice yearly, for the convenience of automatic filtershipme ntill decide to cancel the automatic shipment in writing.Tl		
	45-5272 or by sending a letterto: Blueair Inc., 17 North		
Chicago, IL 60602, includ	dinga signature.		
lame of cardholder			
ype of credit card			
ype of credit card			
redit card number			
xpiration date			
дричнопичес			
uthorizedsignature			



BUSINESS REPLY MAIL

FIRSTCLASSMAIL PERMITNO 21034-001 C

CHICAGO IL

POSTAGE WILL BE PAID BY ADDRESSEE



BLUEAIR INC 17 N. State St., Ste. 1830 CHICAGO IL 60602

httatlandlamittimbilahdalahdalahd

PLEASE FOLD AND SEAL WITH TAPE OR GLUE. DO NOT STAPLE

Blueair 300/400 Series

Filter Subsription

NO POSTAGE
NECESSARY
IF MAILED
IN THE
UNITED STATES

Slueair300

Size of Product

Height Width Depth

21 17 10 (inch) 530 440 250 (mm)

Weight:

24 lbs. 11 kg

Room Size (According to AHAM):

283 sq.ft. 26 m²

CADR (Clean Air Delivery Rate-AHAM):

Smoke 200 Dust 210 Pollen 210 (CFM)

Airflow Rate:

Max Speed: 200 CFM 336 m³/ł

Power Consumption:

20 to 75 W

Noise Level (Sound Power Level):

Speed 1: 32 dB(A)

CONTACT BLUEAIR

Have questions about your Blueair Air Purifier or replacement filters? Contact your local dealer or Blueair at the address below:

Blueair, Inc.

17 N. State St., Ste. 1830

Chicago, IL 60602 Phone: 312 727 1152 Fax: 312 727 1153 www.blueair.com info@blueair.com Blueair400

Size of Product

 Height
 Width
 Depth

 23
 20
 11 (inch)

 590
 500
 275 (mm)

Weight:

34 lbs. 15.5 kg

Room Size (According to AHAM):

365 sq.ft. 34 m²

CADR (Clean Air Delivery Rate-AHAM)

Smoke 235 Dust 253 Pollen 240 (CFM

Airflow Rate:

Max Speed: 260 CFM 440 m³/h

Power Consumption:

20 to 75 W

Noise Level (Sound Power Level):

Speed 1: 32 dB(A

CLEAN AIR
IS A HUMAN RIGHT

